## INSTALLATION INSTRUCTIONS

## Please Note Before Installation

Hardware Resource Company (HRC) cannot control the use or installation of add-on, spare, or replacement parts. Therefore, HRC shall have no responsibility for injury or damage resulting from improper installation or other misuse. Parties undertaking use of these parts assume full responsibility for following proper installation procedures.

## Instructions for installing replacement connecting hardware kits

- <u>.</u> be performed by qualified personnel only. to install product into a switchboard or panelboard while energized. Installation of this product should Ensure all electrical power and voltage has been turned off, locked off, and tagged out. Do not attempt
- 2) a calibrated voltage detection instrument After electricity has been locked off and tagged out, confirm that no electrical current is present by using
- <u>છ</u> Remove dead front cover plates as necessary to gain access to work area
- 4. Tighten screws or bolts to finger tight at this point De-energized bus bar should now be exposed. Install the B phase (center phase) connector first.
- 5. Install out side phase connector(s), and tighten with fingers
- <u>რ</u> Install bus bar anti-turn devices if provided. (Not all kits utilize anti-turn devices.)
- 7.) Install circuit breaker or switch mounting brackets if provided
- <u>,</u> components parts. (Circuit breaker or switch is not included in this kit.) If available, place the circuit breaker or switch into its intended location to verify proper alignment and fit. If not available, refer to the attached assembly drawings for proper dimensions and locations of
- 9. visible obstructions or foreign materials present that might before continuing. conductors. Remove any obstructions or foreign materials reduce proper electrical clearances, or damage insulated After proper alignment has been verified, tighten all bus connections with a calibrated torque wrench to the values in table to the right. Check to be sure there are no
- <u>10</u>.) If not available, go to step 11 If available, install circuit breaker or switch onto connectors
- 11.) Install circuit breaker or switch filler plates when provided (Some may not be required with twin-mounted breakers)
- 12.) shall re-energize any switchboard or panel board re-apply power to the equipment. Only qualified personnel switchboard or panelboard without first following all safety and procedural practices necessary to ensure it is safe to Re-install dead front cover plates. Do not re-energize the

Torque Va Aluminur Bolt Size Inch, (mm)	Torque Values for Copper or Aluminum Bar Connections 3olt Size Torque nch, (mm) lb, - in.	Copper or nnections Torque lb, - in.
Bolt S Inch, (	ize mm)	Torqu lb, - i
#10		30
1/4	(6.4)	65
5/16	(7.9)	128
3/8	(9.5)	240
1/2	(12.7)	600

## *NOTICE*

PRODUCT BY THE MANUFACTURER. TRADEMARK IS THE USE OF THE ORIGINAL EQUIPMENT MANUFACTURER'S AND DOES NOT REPRESENT AN ENDORSEMENT OF THIS FOR INFORMATIONAL PURPOSES



₩ 1.	ZSOAMP MOUNTING HARDWARE FOR FD62, FD63, HFD BREAKERS IN FC1 TYPE PANEL TWIN MOUNT
URA≪ING NO.	SIEMENS / ITE

LAYER F D 6 B RE < REV-B AA 08-02-04 REV'D DWG ND. ITEM #5 REV-A AA 10-23-02 ADDED FISH PAPER, CHANGED KIT # 1/4-20 X 1.250° SELF TAP BOLT
1/4-20 X 1.500° SELF TAP BOLT
1/4-20 X 1.000° SELF TAP BOLT
1/4-20 X .625° SELF TAP BOLT
1/4-20 X 4.000° RD HEAD SCREW 1/4-20 X .500" CARRIAGE BOLT

/4-20 X 1.250" \ /4-20 X 1.500" \

21H-B153F D6-00

무

